



# NDEZJA DHE FIKJA E KASES BEHET DUKE MBAJTUR BUTONIN C SHTYPUR




Vetem ne Regjimin R mund te bejme shitje, te priten kupona.

## MENYRAT E SHITJEVE


### Shitje me artikuj pa çmime




### Shitje me artikuj pa çmime



### Shitje me artikuj me çmime



### Shitje me fatur TVSH-je



# MBYLLJA DITORE (E DETYRUAR ÇDO DITE PUNE)

---

(edhe nese nuk eshte bere asnje shitje)

5 minuta para mbylljes ditore vendoset modemi ne prize.



## Mbyllja ditore behet vetem nje here ne dite

NESE TRASMETIMI NUK KRYHET (TRASMETIM JO) BEHET TRASMETIMI MANUAL


## Trasmetimi manual



Trasmetimin manual mund ta bejme disa here dhe ne cdo kohe

## LEXIMI I GJENDJES SE ARKES


---



## FUNKSIONE TE AVANCUARA

---

### RAPORTI I ARTIKUJVE TE SHITUR



### LEXMI I XHIROS TOTALE (NGA:,DERI:)



SHEMBULL

NGA: 05/10/10 → Totale

NE: 06/10/10 → Totale

### LEXMI I KUPONAVE TE PRERE (NGA:,DERI:)



# REGJISTRIMI I ARTIKUJVE

**4** → **REGJIM** → Shtypim 3 here butonin **NENTOTALE**

, ben hapsire

**X** bene germa te mdha/vogla

00 fshine karakterin

↓  
**TOTALE**

↓  
VENDOSIM KODIN E ARTIKULLIT

E shtypim2 here kur del  
kod i ri

↓  
**TOTALE**

↓  
SHKRUAJM EMRIN E ARTIKULLIT

↓  
**TOTALE**

↓  
VENDOSIM CMIMIN OSE JO

Shtypim 3 here

↓  
**TOTALE**

↓  
**1.**

↓  
**TOTALE**

↓  
**2.**

↓  
**TOTALE**

↓  
**2.**

↓  
**TOTALE**

← ← **FUND**

Per te dal shtypim 3 here

↓  
**FUND**

→ **1**

→ **REGJIM**

←

